1



Ice packs are received dehydrated

2



Place ice pack in water for 10-20 minutes, until saturated

3



Remove once saturated

4



Place in freezer until solid

5



Add to sampling kit once sample is taken and ready for pick up

WATER CHECK
WATER QUALITY CONSULTANTS & ANALYSIS

SANS 241
STANDARDS ALIGNED

SANAS-ACCREDITED
PARTNER LABS

100% INDEPENDENT
& UNBIASED ADVICE

info@watercheck.co.za