1



Your Sampling kit is received with a bottle, ice-pack and alcohol swab. Plan your sampling.

2



Prepare for sampling, pre-label your bottle with sample name, water type and date.

3



Wash your hands to ensure clean sampling.

4



Remove and any attachments or aerators.

5



Flame spout or clean with alcohol swab provided.

6



Purge tap water for 2-3 minutes. Cold tap only.

7



Remove cap just before sampling. Do not touch the inside of the bottle or cap.

8



Fill bottle, leaving a 2cm space

9



Repack your kit: ensure your sample is labelled. Pack your sample and ice-pack back in box ready to ship. Stick waybill sticker on box or write number on the box.

WATER CHECK
WATER QUALITY CONSULTANTS & ANALYSIS

info@watercheck.co.za

SANS 241
STANDARDS ALIGNED

SANAS-ACCREDITED
PARTNER LABS

100% INDEPENDENT
& UNBIASED ADVICE